

Link do produktu: <https://www.strefainternetowa.com/brzeszczot-wglebny-do-drewna-10x40mm-50crv-p-1265.html>



Brzeszczot wgłębny do drewna 10x40mm 50CRV

Cena	20,80 zł
Numer katalogowy	ALP-18502912834
Kod producenta	SCH04B03001
Kod EAN	5902004765990

Opis produktu

Brzeszczot wgłębny do drewna 10x40mm 50CRV

Symbol: SCH04B03001

Brzeszczot wgłębny do drewna 10x40mm 50CRV to wysokiej jakości narzędzie zaprojektowane do precyzyjnego i efektywnego cięcia różnych materiałów, takich jak drewno i PVC. Wykonany z wytrzymałej stali chromowo-wanadowej (50CRV), brzeszczot charakteryzuje się wyjątkową trwałością i odpornością na zużycie, co zapewnia długą żywotność narzędzia. Ostrze wyposażone w 18 zębów na cal (18T) umożliwia szybkie i czyste cięcie, minimalizując ryzyko uszkodzenia obrabianego materiału. Stal wysokowęglowa (HCS) użyta w produkcji tego brzeszczotu zapewnia doskonałą ostrość i długowieczność ostrza, co sprawia, że narzędzie to jest idealne do intensywnej eksploatacji. Dzięki kompaktowym wymiarom 10x40mm, brzeszczot umożliwia pracę w trudno dostępnych miejscach, co zwiększa jego wszechstronność i użyteczność w różnych projektach.

Dane techniczne:

- Rozmiar: 10x40mm
- Materiał: 50CRV (stal chromowo-wanadowa)
- Zęby na cal: 18T
- Typ: HCS (High Carbon Steel)
- Zastosowanie: Drewno, PVC

Parametry produktu

- **Stan:** Nowy
- **Marka:** Schmith
- **Liczba elementów w zestawie:** 1
- **Zastosowanie:** drewno
- **Typ uchwytu:** uniwersalny
- **Rodzaj brzeszczotu:** do urządzeń wielofunkcyjnych
- **Materiał wykonania:** HCS
- **Kod producenta:** SCH04B03001
- **Długość (mm):** 40
- **Szerokość:** 10
- **EAN (GTIN):** 5902004765990

Informacje o bezpieczeństwie

List of blade safety warnings based on the requirements of General Product Safety Regulation (EU) 2023/988 (GPSR). * Use appropriate personal protective equipment, such as safety glasses and gloves, to protect yourself from chipping and sharp edges. * Choose the right saw blades for the material you intend to cut to avoid tool damage and injury. * Regularly check the condition of the saw blades to ensure they are not cracked, bent, or worn out. Damaged saw blades can break during operation and pose a threat. * Ensure that the saw blade is properly attached to the tool to avoid it loosening or falling out during operation. * Do not overload the saw blade, apply the right pressure and cutting speed to avoid overheating and cracking. * Be aware of the risk of injury when replacing saw blades. Always disconnect the tool from power and use protective gloves. * Store saw blades in a safe place, out of reach of children, to avoid accidental cuts. * Use the saw blades according to the tool manufacturer's instructions to ensure safety and efficiency. * Pay attention to the cutting direction of the saw blade and make sure that it is consistent with the direction of the tool. * Do not use saw blades for purposes incompatible with their intended purpose, e.g. for prying or bending. * Keep your saw blades clean, remove impurities, and lubricate to prevent corrosion and increase their durability.

Producent — dane kontaktowe

Schmith Polska S.A.
ul. Wschodnia 8
83-110
Tczew
PL
biuro@schmith.pl