Dane aktualne na dzień: 27-10-2026 16:43

Link do produktu: https://www.strefainternetowa.com/brzeszczoty-do-wyrzynarki-hcs-50crv-100mm-10tpi-2-p-1904.html

Brzeszczoty do wyrzynarki HCS 50CRV 100mm 10TPI 2

Cena	**16,02 zł**
Numer katalogowy	**ALP-18040529750**
Kod producenta	**SCH04B01009**
Kod EAN	**5902004754338**

Opis produktu

Brzeszczoty do wyrzynarki typ T101BR 100mm 10TPI 2szt.

Symbol: SCH04B01009

Wąski , cienki brzeszczot umożliwiający wycinanie okrągłych konturów o bardzo małych promieniach.

- wykonane z wysokowęglowej stali narzędziowej HCS
- dłuższa żywotność
- typ T101BR
- 10TPI
- długość 100mm

Parametry produktu

- **Stan:** Nowy
- **EAN (GTIN):** 5902004754338
- **Kod producenta:** SCH04B01009
- **Marka:** Schmith
- **Liczba elementów w zestawie:** 2
- **Zastosowanie:** drewno
- **Rodzaj brzeszczotu:** do wyrzynarek
- **Typ uchwytu:** teowy (T)
- **Długość (mm):** 100
- **Materiał wykonania:** HCS

Informacje o bezpieczeństwie

List of blade safety warnings based on the requirements of General Product Safety Regulation (EU) 2023/988 (GPSR). * Use appropriate personal protective equipment, such as safety glasses and gloves, to protect yourself from chipping and sharp edges. * Choose the right saw blades for the material you intend to cut to avoid tool damage and injury. * Regularly check the condition of the saw blades to ensure they are not cracked, bent, or worn out. Damaged saw blades can break during operation and pose a threat. * Ensure that the saw blade is properly attached to the tool to avoid it loosening or falling out during operation. * Do not overload the saw blade, apply the right pressure and cutting speed to avoid overheating and

cracking. * Be aware of the risk of injury when replacing saw blades. Always disconnect the tool from power and use protective gloves. * Store saw blades in a safe place, out of reach of children, to avoid accidental cuts. * Use the saw blades according to the tool manufacturer's instructions to ensure safety and efficiency. * Pay attention to the cutting direction of the saw blade and make sure that it is consistent with the direction of the tool. * Do not use saw blades for purposes incompatible with their intended purpose, e.g. for prying or bending. * Keep your saw blades clean, remove impurities, and lubricate to prevent corrosion and increase their durability.

Producent — dane kontaktowe

Schmith Polska S.A.
ul. Wschodnia 8
83-110
Tczew
PL
biuro@schmith.pl