Dane aktualne na dzień: 27-10-2026 21:26

Link do produktu: https://www.strefainternetowa.com/schmith-brzeszczot-do-wyrzynarki-typ-t119bo-75mm-12tpi-2szt-do-drewna-p-3392.html

SCHMITH BRZESZCZOT DO WYRZYNARKI TYP T119BO 75mm 12TPI 2SZT DO DREWNA

Cena	**15,00 zł**
Numer katalogowy	**ALP-15289407810**
Kod producenta	**SCH04B01001**
Kod EAN	**5902004754253**

Opis produktu

Brzeszczoty do wyrzynarki typ T119BO 75mm 12TPI 2szt.

Symbol: SCH04B01001

Wąski , cienki brzeszczot umożliwiający wycinanie okrągłych konturów o bardzo małych promieniach.

- wykonane z wysokowęglowej stali narzędziowej HCS
- dłuższa żywotność
- typ T119BO
- długość 75mm
- 12TPI

Parametry produktu

- **Stan:** Nowy
- **Marka:** Schmith
- **EAN (GTIN):** 5902004754253
- **Kod producenta:** SCH04B01001
- **Zastosowanie:** drewno
- **Rodzaj brzeszczotu:** do wyrzynarek
- **Typ uchwytu:** teowy (T)
- **Liczba elementów w zestawie:** 2

Informacje o bezpieczeństwie

List of blade safety warnings based on the requirements of General Product Safety Regulation (EU) 2023/988 (GPSR). * Use appropriate personal protective equipment, such as safety glasses and gloves, to protect yourself from chipping and sharp edges. * Choose the right saw blades for the material you intend to cut to avoid tool damage and injury. * Regularly check the condition of the saw blades to ensure they are not cracked, bent, or worn out. Damaged saw blades can break during operation and pose a threat. * Ensure that the saw blade is properly attached to the tool to avoid it loosening or falling out during operation. * Do not overload the saw blade, apply the right pressure and cutting speed to avoid overheating and cracking. * Be aware of the risk of injury when replacing saw blades. Always disconnect the tool from power and use protective gloves. * Store saw blades in a safe place, out of reach of children, to avoid accidental cuts. * Use the saw blades according to the tool manufacturer's instructions to ensure safety and efficiency. * Pay attention to the cutting direction of the saw blade and make sure that it is consistent with the direction of the tool. * Do not use saw blades for purposes incompatible with their intended purpose, e.g. for prying or bending. * Keep your saw blades clean, remove impurities, and lubricate to

prevent corrosion and increase their durability.

Producent — dane kontaktowe

SCHMITH POLSKA S.A
KULICE UL.SZKOLNA 4
83-130
PELPLIN
PL
kontakt@schmith.pl
696113253