

Link do produktu: <https://www.strefainternetowa.com/brzeszczot-okragly-do-drewna-88mm-hcs-p-1251.html>



Brzeszczot okrągły do drewna 88mm HCS

Cena	29,74 zł
Numer katalogowy	ALP-18503541752
Kod producenta	SCH04B03011
Kod EAN	5902004766096

Opis produktu

Brzeszczot okrągły do drewna 88mm HCS

Symbol: SCH04B03011

Brzeszczot okrągły do drewna 88mm HCS to wysokiej jakości narzędzie zaprojektowane do precyzyjnego i efektywnego cięcia drewna i PVC. Dzięki zastosowaniu stali wysokowęglowej (HCS) oraz stali 65Mn, brzeszczot charakteryzuje się doskonałą ostrością i trwałością, co zapewnia długą żywotność narzędzia. Stal 65Mn jest znana z wysokiej wytrzymałości na rozciąganie oraz dobrej elastyczności, co czyni ją idealnym materiałem do narzędzi tnących. Ostrze wyposażone w 18 zębów na cal (18T) umożliwia szybkie i czyste cięcie, minimalizując ryzyko uszkodzenia obrabianego materiału. Rozmiar 88mm pozwala na wszechstronne zastosowanie w różnych projektach, umożliwiając precyzyjną pracę nawet w trudno dostępnych miejscach. Dodatkowo, brzeszczot jest idealny do cięcia PVC, co zwiększa jego uniwersalność.

Dane techniczne:

- Rozmiar: 88mm
- Materiał: HCS (stal wysokowęglowa)
- Zęby na cal: 18T
- Typ: Stal wysokowęglowa 65Mn
- Zastosowanie: Drewno, PVC

Zalety Produktu:

- Precyzja: Ostrze zaprojektowane do czystego i dokładnego cięcia.
- Wytrzymałość: Wysokowęglowa stal zapewnia wydłużoną żywotność ostrza.
- Wszechstronność: Idealny do różnych typów drewna, od miękkiego po twarde.

Parametry produktu

- **Stan:** Nowy
- **Marka:** Schmith
- **Liczba elementów w zestawie:** 1
- **Zastosowanie:** drewno, PCV
- **Typ uchwytu:** uniwersalny
- **Rodzaj brzeszczotu:** do urządzeń wielofunkcyjnych
- **Materiał wykonania:** HCS
- **Kod producenta:** SCH04B03011

-
- **EAN (GTIN):** 5902004766096

Informacje o bezpieczeństwie

List of blade safety warnings based on the requirements of General Product Safety Regulation (EU) 2023/988 (GPSR). * Use appropriate personal protective equipment, such as safety glasses and gloves, to protect yourself from chipping and sharp edges. * Choose the right saw blades for the material you intend to cut to avoid tool damage and injury. * Regularly check the condition of the saw blades to ensure they are not cracked, bent, or worn out. Damaged saw blades can break during operation and pose a threat. * Ensure that the saw blade is properly attached to the tool to avoid it loosening or falling out during operation. * Do not overload the saw blade, apply the right pressure and cutting speed to avoid overheating and cracking. * Be aware of the risk of injury when replacing saw blades. Always disconnect the tool from power and use protective gloves. * Store saw blades in a safe place, out of reach of children, to avoid accidental cuts. * Use the saw blades according to the tool manufacturer's instructions to ensure safety and efficiency. * Pay attention to the cutting direction of the saw blade and make sure that it is consistent with the direction of the tool. * Do not use saw blades for purposes incompatible with their intended purpose, e.g. for prying or bending. * Keep your saw blades clean, remove impurities, and lubricate to prevent corrosion and increase their durability.

Producent — dane kontaktowe

Schmith Polska S.A.
ul. Wschodnia 8
83-110
Tczew
PL
biuro@schmith.pl