

Link do produktu: <https://www.strefainternetowa.com/schmith-podnosnik-hydrauliczny-slupkowy-4t-p-3269.html>



SCHMITH PODNOŚNIK HYDRAULICZNY SŁUPKOWY 4T

Cena	109,00 zł
Numer katalogowy	ALP-16011374738
Kod producenta	SPHS-4
Kod EAN	5902004744582

Opis produktu

Podnośnik hydrauliczny słupkowy 4t

■ PODNOŚNIK HYDRAULICZNY SŁUPKOWY- 4 T

Profesjonalny podnośnik hydrauliczny słupkowy posiadający system zaworów, które precyzyjnie dawkują strugę oleju, co pomimo niewielkiego skoku tłoka zapewnia jego wysoką wydajność pod maksymalnym obciążeniem.

- wykręcana stopa w tłoku podnośnika posiadająca silny, drobnozwojny, trapezowy gwint, odporny na przeciążenia
- tłok pokryty niklem, co sprawia, że powierzchnia jest wygładzona
- solidna konstrukcja zapewnia trwałość i bezpieczeństwo
- niewielki rozmiarem i lekkość ułatwiają przemieszczanie i przechowywanie
- niezbędny w warsztatach samochodowych i stacjach obsługi pojazdów
- certyfikat CE gwarantuje zgodność z europejskimi standardami bezpieczeństwa
- Zakres podnoszenia: 188-363 mm
- Wymiary 108,5 x 87 x 188 mm
- Waga: 2,8 kg



□ PRODUCENT:

SCHMITH

SPHS-4

□ TYP:

Hydrauliczny 4T

□ JEDNOSTKA MIARY:

Parametry produktu

-
- **Stan:** Nowy
 - **EAN (GTIN):** 5902004744582
 - **Kod producenta:** SPS-4
 - **Marka:** Schmith
 - **Udźwig:** 4000
 - **Minimalna wysokość podnoszenia:** 188
 - **Maksymalna wysokość podnoszenia:** 363

Informacje o bezpieczeństwie

List of safety warnings for workshop lifts based on the requirements of Regulation (EU) 2023/988 on general product safety (GPSR). 1. Make sure that the lift is placed on a stable and even surface to prevent it from tipping over during use. 2. Do not exceed the maximum lifting capacity of the lift to avoid damage and potential accidents. 3. Always use vehicle supports when it is raised to protect against sudden lowering. 4. Regularly check the technical condition of the lift, in particular the load-bearing, hydraulic and mechanical components, to ensure that they are not damaged or worn out. 5. When lifting and lowering the vehicle, make sure that there are no bystanders nearby to avoid potential injuries. 6. Do not work under a vehicle that is supported solely by a lift, without additional supports. 7. Store the lift in a dry and safe place to prevent corrosion and damage. 8. Follow the manufacturer's instructions for maintenance and servicing of the lift to ensure its proper operation and safety of use. 9. Use the lift only for its intended purpose, avoid lifting objects of unknown weight or unstable shape. 10. In the event of a lift failure, immediately stop working and contact the service to avoid further damage and potential accidents.

Producent — dane kontaktowe

SCHMITH POLSKA S.A
KULICE UL.SZKOLNA 4
83-130
PELPLIN
PL
kontakt@schmith.pl
696113253