Dane aktualne na dzień: 19-11-2026 11:31

Link do produktu: https://www.strefainternetowa.com/schuller-nozyk-noz-bezpieczny-samurai-safety-18mm-p-3381.html



SCHULLER NOŻYK NÓŻ BEZPIECZNY SAMURAI SAFETY 18MM

Cena	**20,00 zł**
Numer katalogowy	**ALP-15343670677**
Kod producenta	**30588 2**
Kod EAN	**9002588305882**

Opis produktu

SCHULLER NOŻYK SAMURAI SAFETY 18 MM 1 SZT

Bezpieczny nożyk z automatycznym cofaniem ostrza

Opis produktu / charakterystyka :

- wysokiej jakości **nożyk z automatycznym cofaniem ostrza**,
- bezpieczna metalowa prowadnica,
- wysuwane, łamane ostrze,
- ilość segmentów : **8,**
- szerokość ostrza : **18mm,**
- zastosowanie : **do cięcia tapet, kartonów, taśm, kabli, wykładzin**

Seria SAMURAI to wysokiej jakości nożyki, z metalowymi prowadnicami ostrza oraz wymienne ostrza do tych nożyków. Dedykowane są dla profesjonalistów.

Szerokość ostrza: 18mm

Grubość ostrza: 0.5mm

Parametry produktu

- **Stan:** Nowy
- **EAN (GTIN):** 9002588305882
- **Kod producenta:** 30588 2
- **Marka:** Schuller Eh'klar
- **Rodzaj:** nóż
- **Waga produktu z opakowaniem jednostkowym:** 0.13

Informacje o bezpieczeństwie

List of safety warnings for knives and blades based on the requirements of General Product Safety Regulation (EU) 2023/988 (GPSR): * Use knives and blades for their intended purpose. Improper use can lead to cuts. * Blades are sharp - take extra

care during use and storage. * Keep knives and blades out of reach of children and unauthorized persons. * Always use appropriate personal protective equipment, such as gloves, to minimize the risk of injury. * Check the condition of the blades regularly. Blunt or damaged blades can be more dangerous. * Carefully replace the blades by following the manufacturer's instructions. * Never try to catch a falling knife or blade. * Do not use knives and blades if you are tired or under the influence of alcohol or drugs. * Make sure the workpiece is stable before cutting. * After use, secure the blades with a cover or hide in a secure container. * Do not carry knives and blades in your pocket or in a place where they can cause accidental cuts. * When working with knives and blades, keep a safe distance from others. * Do not use knives and blades for purposes other than those for which they are designed. * If the blade gets stuck, do not it by force. Try to gently release them or use the right tool. * Always clean the blades after use to remove material debris and prevent corrosion. * Warn others about the presence of sharp tools in the workplace. * Dispose of used blades safely, in accordance with local regulations. * Do not leave knives and blades in places where they can pose a threat to animals. * Before using knives and blades, make sure you know the rules for safe use.

Producent — dane kontaktowe

Schuller Eh'klar Polska Sp. z o.o.
ul. Przemysłowa 6
62-052
Komorniki
PL
sklep@adecoshop.pl