

Link do produktu: <https://www.strefainternetowa.com/wegiel-drzewny-landmann-premium-5kg-2x2-5kg-zestaw-2-szt-p-1212.html>



WĘGIEL DRZEWNY Landmann Premium 5kg (2X2,5KG) — zestaw 2 szt.

Cena	49,99 zł
Numer katalogowy	ALP-18533147055
Kod producenta	WGD
Kod EAN	4000810009305

Opis produktu

Oferta dotyczy zestawu: 2 szt.

Węgiel drzewny Landmann Premium -

Trudno wyobrazić sobie letni wypoczynek w ogrodzie bez aromatycznych smażonych potraw. Węgiel drzewny Landmann Premium powinien zatem zawsze znajdować się w altanie. Produkt długo się pali, oddając sporo energii. Dzięki temu już jedno opakowanie wystarczy do przygotowania potraw dla wielu gości. Dużą jego zaletą jest łatwość rozpalenia.

- łatwy w rozpalaniu
- długi czas palenia
- minimalna ilość popiołu

Parametry logistyczne

- **Wymiary produktu:** 22 x 40 x 12 cm
- **Długość opakowania:** 12 cm
- **Waga brutto:** 2.5 kg
- **Waga w opakowaniu:** 2,5 kg

Parametry techniczne i użytkowe

- **Obszary zastosowania:** paliwo do grilli węglowych

Parametry indywidualne

- **Marka:** Landmann

Parametry fizyczne i wizualne

- **Materiał wykonania:** węgiel drzewnego

Parametry produktu

-
- **Stan:** Nowy
 - **Stan opakowania:** oryginalne
 - **Kod producenta:** WGD
 - **Marka:** Landmann
 - **Typ produktu:** węgiel
 - **Waga:** 2.5
 - **EAN (GTIN):** 4000810009305

Informacje o bezpieczeństwie

List of fire starter and briquette safety warnings based on the requirements of General Product Safety Regulation (EU) 2023/988 (GPSR): * Use fire starters and briquettes in accordance with the manufacturer's instructions. Improper use can lead to fire or explosion. * Store fire starters and briquettes in a dry, cool place, away from heat sources and open fire. * Use fire starters and briquettes outdoors or in a well-ventilated area. Burning in a closed room can lead to carbon monoxide poisoning. * Do not use gasoline, kerosene, or other flammable liquids to light the grill. Use special fire starters designed for this purpose. * Do not leave a hot grill unattended. * Keep children and pets away from the hot grill. * After use, make sure the ash is completely cooled before removing it. * Do not throw hot ash in the trash can. * If you swallow or come into contact with your eyes, contact your doctor immediately. * Do not use fire starters and briquettes for purposes other than grilling. * Check that the grill is stable and set on an even surface. * Use protective gloves when manipulating a hot grill. * For gas grills, check the tightness of wires and connections before each use. * For electric grills, make sure the power cable is not damaged.

Producent — dane kontaktowe

Landmann GmbH & Co. Handels-KG
Am Heisterbusch 1
27711
Osterholz-Scharmbeck
DE
service@landmann.de